MDX-100/100RDS

SONY. SERVICE MANUAL

US Model
Canadian Model
E Model
MDX-100
AEP Model
UK Model
MDX-100RDS

SUPPLEMENT-1

File this supplement with the service manual.

Subject:

- Test Mode
- Electrical Adjustments

TEST MODE

Setting the Test Mode

Operate the steps 1 to 3 shown below without a disc.

- Press 4.
 Press 5. 2.
- Press 1 for 2 seconds.

All the display light up and the Test Mode is set.


Note: If a disc is inserted in this case, "SHUF 1" lights up and it becomes VOL MAX PLAY.

When canceling the test mode, press OFF button.

Setting and Function of Servo Adjustment Mode

- 1) After the Test Mode, press MD button to set Servo Adjustment Mode.
- 2) Function of the each button in Servo Adjustment Mode.
 - 1: FOCUS ON
 - 2: TRACKING ON
 - 3: LASER ON (MO)
 - 4: STOP

 - [KK AMS/SEEK+ DD]: AMS ± (Only in PLAY)
 - 📤 : EJECT
 - OFF: RESET (Canceling the Test Mode)
- 3) Insert a disc to press $\boxed{1} \rightarrow \boxed{2}$, and it plays without sound. Data is read discontinuously in the PLAY in normal mode, but in this mode, the eye pattern of the continuous reading is observed with oscilloscope. VOL MAX is received with TUNER → MD.
- 4) Checking FOCUS, TRACKING ON



- is blinking: FOCUS ON
- ■ is "MD": TRACKING ON
- When canceling Servo Adjustment Mode, press TUNER or cancel the Test Mode by pressing OFF.

2. ELECTRICAL ADJUSTMENTS


MINI DISC SECTION

Precaution in the Confirmation of Laser Diode Radiation

Do not look in from the top in confirming the radiation of Laser Diode for fear of the loss of eyesight.

Precaution in the Handling of Mini-Disc Device (KMS-150A)

Solder-bridge the laser tap of flexible board in handling the Laser Diode in the optical pick-up since it is very easy to be destroyed in the static electricity. Be fully prepared for the prevention of electrostatic destruction. Be careful in handling the flexible board since it is easy to be cut.



Optical Pick-Up Flexible Board

Precaution in the Adjustment

- All the adjustment should be performed in order of the Test Mode. Cancel the Test Mode by pressing OFF button after the adjustment.
- 2) In some cases, SLED shift by

 dd MANU/DISC +
 button or EJECT movement by
 button do not work. In those cases, cancel the Test Mode by pressing OFF button and reset the Test Mode.
- 3) Instrument and measure are shown below.
 - CD Test Disc TDYS-1

(Parts Code: 4-963-646-01)


- Recorded MO Disc PTDM-1 (Parts Code: J-2501-054-A)
- Laser Power Meter LPM-8001

(Parts Code: J-2501-046-A)

- Oscilloscope (Band over 40 MHz. Measure after performing CAL of probe.)
- · Digital Voltmeter

Laser Power Adjustment


1) Adjustment by Laser Power Meter Connection:



Procedure:

- 1. Turn RV529 fully counterclockwise.
- 2. Set it Servo Adjustment Mode of the Test Mode.
- 4. Press 3 button.
- 5. Adjust RV529 so that the Laser Power Meter shows 820 \pm 5 μ W.
- 6. Press 4 button.
- 2) Adjustment by an eye pattern.

Connection:




Procedure:

- Turn RV529 fully counterclockwise.
- 2. Load and play back the CD Test Disc.
- 3. Adjust RV529 for an eye pattern of 1.5 Vp-p.



FOK Offset Adjustment

Connection:




Procedure:

- Connect a Digital Voltmeter between TP (ABCD) and TP (VC) of MD servo board.
- 2. Set it Servo Adjustment Mode of the Test Mode.
- 3. Press 3 button.
- 4. Adjust RV510 for -200 ± 50 mV on the voltmeter.
- 5. Press 4 button.

Tracking Offset Adjustment

Connection:




Procedure:

- Connect a Digital Voltmeter between TP (TE) and TP (VC) of MD servo board.
- 2. Set it Servo Adjustment Mode of the Test Mode.
- 3. Press 3 button.
- 4. Adjust RV521 for 0 ± 50 mV on the voltmeter.
- 5. Press 4 button.

Premastered Focus Bias Adjustment

Connection:




Procedure:

- 1. Connect a Digital Voltmeter between TP (FE) and TP (VC) of MD servo board.
- 2. Set it Servo Adjustment Mode of the Test Mode.
- 3. Press 3 button, then 4 button.
- 4. Adjust RV518 for 0 ± 10 mV on the voltmeter.
- 5. Press 4 button.

MO Focus Bias Adjustment

Connection:




Procedure:

- 1. Connect a Digital Voltmeter between TP (FE) and TP (VC) of MD servo board.
- 2. Set it Servo Adjustment Mode of the Test Mode.
- 3. Press 3 button.
- 4. Adjust RV517 for -300 ± 10 mV on the voltmeter.
- 5. Press 4 button.

E-F Balance Adjustment

Connection:




Procedure:

- Connect the Digital Voltmeter between TP (TE) and TP (VC) of MD servo board.
- 2. Set it Servo Adjustment Mode of the Test Mode.
- 3. Move the optical pick-up to the most inside by keeping pressing \ button.
- 4. Press button once. (The SLED moves 1 step to the outer circumference.)
- 5. Load an MO disc.
- 6. Press 1 button for focus on.
- 7. Adjust RV528 for 0 ± 100 mV on the voltmeter.
- 8. Press 4 button.
- 9. Press button to eject the disc.

Focus Gain Adjustment

Connection:




Procedure:

- 1. Connect as shown above.
- 2. Set it Servo Adjustment Mode of the Test Mode.
- 3. Move the optical pick-up to the most inside by keeping pressing \ button.
- 4. Press button once. (The SLED moves 1 step to the outer circumference.)
- 5. Load an MO disc.
- 6. Press 1 button for focus on.
- 7. Press 2 button for tracking.
- 8. Adjust RV543 so that the waveform observed on the oscilloscope is symmetrical to the vertical line at the center, as shown in figure (b).
- 9. Press 4 button.

10. Press | button to eject the disc.

Note: The level of ch. 1 (X) and ch. 2 (Y) are different by 10 times. Adjust the range of the oscilloscope so that observation is done in the same level.

(Lissajous Waveform)
Range: ch. 1 (X) = 20 mV
ch. 2 (Y) = 200 mV




(a) Gain is too low. (b) Gain is appropriate. (c) Gain is too high.

Tracking Gain Adjustment

1) Method by the Lissajous Waveform.

Connection:



Procedure:


- 1. Connect as shown above.
- 2. Set it Servo Adjustment Mode of the Test Mode.
- 3. Move the optical pick-up to the most inside by keeping pressing \ button.
- 4. Press button once. (The SLED moves 1 step to the outer circumference.)
- 5. Load an MO disc.
- 6. Press 1 button for focus on.
- 7. Press 2 button for tracking.
- 8. Adjust RV542 so that the Lissajous Waveform on the oscilloscope is circle.
- 9. Press 4 button.
- 10. Press button to eject the disc.

Note: 1. The level of ch. 1 (X) and ch. 2 (Y) are different by 10 times. Adjust the range of the oscilloscope so that observation is done in the same level.


2. In case that the Lissajous Waveform is not confirmed with the method shown above, perform with the summary adjustment method.

(Lissajous Waveform)

Range: ch. 1 (X) = 20 mV ch. 2 (Y) = 200 mV



(a) Gain is too low. (b) Gain is appropriate. (c) Gain is too high.



TUNER SECTION


· Precaution in reparing

When front-end part is defective, exchange the whole front-end part since it is difficult to repair its inside.

FM Auto Scan/Stop Level Adjustment

Setting:

BAND switch: FM



Carrier frequency:

97.9 MHz (US/Canadian)

98.0 MHz (Except US/Canadian)

Output level: Mode:

22 dB


mono, unmodulated

Procedure:

1. Set it the Test Mode.


Press the TUNER button and set it FM.

Display window (EX: US/Canadian)



3. Press SEEK + ▶▶ button and adjust the built-in volume RV3 of TU1 so that "FM" indication turns to "FM0" on the display window. When the display window indicates "FM0" before the adjustment, start the adjustment after turning off the "0" indication by turning RV3.

Display window (EX: US/Canadian)



Standard Value: Stop response 22 dB ± 3 dB

Note: "0" indication is tuning with the voltage of SD terminal (see page 9).

SD terminal voltage 0 V → "0" OFF


SD terminal voltage 5 V \rightarrow "0" ON

AM Auto Scan/Stop Level Adjustment

Precaution: This adjustment should be performed after the FM auto scan/stop adjustment.

Setting:

BAND switch: AM



Frequency:

1000 kHz (US/Canadian) 999 kHz (Except US/Canadian)

Output level:

33 dB

Modulation:


30% AM modulation

Procedure:

Set it Test Mode.


Press the TUNER button to set AM.

Display window (EX: US/Canadian)



3. Press SEEK + ▶▶ button and adjust the built-in volume RV1 of TU1 so that "AM" indication turns to "AM0" on the display window. When the display window indicates "AMO" before the adjustment, start the adjustmet after turning off the "0" indication by turning RV1.

Display window (EX: US/Canadian)



Standard Value: Stop response 33 dB ± 3 dB

Note: "0" indication is tuning with the voltage of SD terminal (see page 9).


SD terminal voltage 0 V → "0" OFF

SD terminal voltage 5 $V \rightarrow$ "0" ON

High Cut Control Effect Adjustment

Setting:

BAND switch: FM



Carrier frequency: 97.9 MHz (US/Canadian) 98.0 MHz (Except US/Canadian)

Output level: Mode:

60 dB (1 mV) mono

Modulation:

10 kHz, 40 kHz deviation

Procedure:

Tune it to 97.9 MHz or 98.0 MHz. This output level should


2. Adjust the built-in volume RV2 of TU1 so that the output level when SSG input is 20 dB is (A) - 5 dB.

Adjustment Location: MAIN board TU1

FM Noise Convergent Point Adjustment

Setting:

Band switch: FM



Carrier frequency:

97.9 MHz (US/Canadian)

98.0 MHz (Except US/Canadian)

Output level: Modulation:

60 dB (1 mV) main; 1 kHz, 33.75 kHz deviation sub; 1 kHz, 33.75 kHz deviation

19 kHz pilot; 7.5 kHz deviation

Procedure:


1. Tune it to 97.9 MHz or 98.0 MHz. This output level should be (B) dB.

Adjust the built-in volume RV5 of TU1 so that the noise level when SSG input is OFF is (B) -30 dB.

FM Stereo Separation (60 dB) Adjustment

Setting:

BAND switch: FM



Carrier frequency:

97.9 MHz (US/Canadian)

98.0 MHz (Except US/Canadian)

Output level: Modulation:

60 dB (1 mV) main; 1 kHz, 33.75 kHz deviation sub; 1 kHz, 33.75 kHz deviation 19 kHz pilot; 7.5 kHz deviation

Procedure:

1. Adjust the built-in volume RV4 of TU1 for the best separation.

FM stereo signal generator output channel	VTVM connection	VTVM reading (dB)
L-CH	L-CH	(A)
R-CH	L-CH	Adjust RV4 for VTVM minimum reading.
R-CH	R-CH	0
L-CH	R-CH	Adjust RV4 for VTVM minimum reading.

L-CH Stereo separation: A - B R-CH Stereo separation: © - ©


The separations of both channels should be equal.

Adjustment Location: MAIN board TU1 Standard Value: Separation over 30 dB.

S Meter Adjustment (MDX-100RDS)

Setting:

BAND switch: FM



Procedure:


1. Set it the Test Mode.

2. Press the TUNER button and set it FM.

3. Press the 10 button and set it AD value and adjust the volume RV501 so that the AD value is 11.8.



Adjusting Parts Location



English 94G0586-1 Printed in Japan © 1994. 7